

FIGURE 1. RCU-3 and RCU-4 remote connections to "C" Seriespanels.




FIGURE 2. RCU-3 remote connections to EUR-5A.





UNPACKING

Inspect the shipping container and packing material for damage. Save the shipping container and related materials until normal operation has been established. If the unit must be returned, take care to ensure that it is packed as it was received.

PACKING LIST

RCU-3

11000	
21357 18581 21385 21370	RCU-3 Remote Control Unit (Qty 1) Wall plate screws (Qty 2) 25' unshielded 22 gauge 2-wire jacketed cable RCU-3/RCU-4 Installation Manual
RCU-4	
21358 18581 21385 21370	RCU-4 Remote Control Unit (Qty 1) Wall plate screws (Qty 2) 25' unshielded 22 gauge 2-wire jacketed cable RCU-3/RCU-4 Installation Manual

ORDERING INFORMATION

nree Phase		
Phase		
nree Phase		
Phase		
Hz Three Phase		
ingle Phase		
Hz Three Phase		
hree Phase		
Control Panel Accessories		
Pro) (Qty 1 included EUR-5A only)		
0C & GF-Pro)		
uded)		

Snow/Ice Sensors (Not Included)

10001	CIT-1 Aerial Snow Sensor
11351	GIT-1 Gutter Ice Sensor
24219	SIT-6E Pavement Mounted Snow/Ice Sensor

LIMITED WARRANTY

ETI's two year limited warranty covering defects in workmanship and materials applies. Contact Customer Service for complete warranty information.

DISCLAIMER

ETI makes no representations or warranties, either expressed or implied, with respect to the contents of this publication or the products that it describes, and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. ETI reserves the right to revise this publication, and to make changes and improvements to the products described in this publication, without the obligation of ETI to notify any person or organization of such revisions, changes or improvements.

The ETI logo, Snow Switch, Floorstat, Tracon, We Manage Heat, APS, RCU, CIT, GIT, SIT are registered trademarks of ETI. Copyright © 2012 ETI All rights reserved.